



MAG-FAST® User's Guide

A guide to help you get the most out of your new MAG-FAST AR-15 mount

August 1, 2014

MAG-FAST IS A BUSINESS UNIT OF AUREUS CONSULTING, LLC

MAG-FAST® User's Guide

A guide to help you get the most out of your new MAG-FAST AR-15 mount

Introduction:

Congratulations on your purchase of a MAG-FAST® mount for your AR-15 Pattern rifle/carbine. You now have one of the most innovative locking mounts available. Designed especially to mount an AR-15, the MAG-FAST® will keep your home defense or personal defense carbine safe from unauthorized use while keeping it ready in case you ever need it in a hurry.

Now that you have installed your MAG-FAST® locking rifle mount, there are just a few things that we should say about its use.

The Key to Security is the Security of the Key:

This may sound circular, but it is literally the truth. If you don't control access to the key for your MAG-FAST® then your MAG-FAST® is powerless to control the access to your AR-15 rifle and it will be powerless to prevent the unauthorized use of your AR-15 by children, relatives or thieves that have broken into your home. This may sound obvious, but the consequences of losing that control, in addition to being criminal in many jurisdictions, can be devastating to any family.

Your MAG-FAST® came from the factory with two matching keys. Before you begin to use the MAG-FAST®, you should come up with a key security plan that you can follow religiously. Whether you choose to leave one key in a locked safe and one key on a key ring of which you maintain exclusive control, or you choose to leave one key in a safe deposit box and the other in a locked box in the house or you use some other method of controlling access to the keys, you must follow your plan if you want the MAG-FAST® to control access to your rifle.

Mounting an AR-15 to the MAG-FAST®:

To mount your rifle on the MAG-FAST®, first remove any magazine that might be inserted in the rifle and secure the bolt in the open position. Next, verify that the MAG-FAST® lock is unlocked by pushing in on the steel locking balls that protrude from their holes near the end of the "magazine" of the MAG-FAST® (see Figure 1). If the locking balls sit flush with the surface of the MAG-FAST®, then the unit is unlocked, and you can slide the AR-15's

magazine well onto the magazine body of the MAG-FAST[®]. When it is fully mounted, you should hear a click from the rifle's magazine catch engaging the mating surface of the MAG-FAST[®]. At this point, you can lock the MAG-FAST[®] by turning the key counter-clockwise until you feel or hear the lock snap into place.




FIGURE 1: LOCATION OF LOCKING BALLS

The feeling should be identical to the feeling you get when you lock the deadbolt on your house. The first few times you lock the unit, you may want to verify that the rifle is secured. You can do this by depressing the magazine release on the rifle and attempting to slide it off of the MAG-FAST[®]. You won't hurt that MAG-FAST[®] by doing this, but remember that the locking balls are hardened steel and they will mar the finish on the inside of your

upper receiver if you attempt to force the AR-15 off of the MAG-FAST[®] while the system is secured by the lock. Alternatively, you can verify that the system is locked by feeling the locking balls through the ejection port of the upper receiver. If the balls will not retract into their holes when pushed in firmly, then the system is secure.

Retrieving an AR-15 from the MAG-FAST[®]:

Unlock the MAG-FAST[®] by inserting the key and turning it clockwise until you hear a click. While depressing the magazine release on the rifle's lower receiver, slide the rifle off of the MAG-FAST[®]. Your rifle should now be in your hand and ready to load and use if necessary.

Maintenance of the MAG-FAST[®]:

If you ever need to clean the MAG-FAST[®] system, you should use a clean, dry, lint-free towel to wipe the surface down. In normal, indoor residential use, it should not require any routine lubrication or special maintenance. Since some environments are inordinately dusty and dirty, you should verify that your MAG-FAST[®] is working smoothly by unlocking and removing the rifle at least once every two months. If you find that lint is accumulating, a vacuum cleaner can be used to clean the area where the locking balls are located.

Contact Us If You Have Any Questions:

We appreciate your purchase of a MAG-FAST® rifle mount and we are ready to help you incorporate it into your home security plan in any way we can. If there are any questions that we can help you with, please contact us through the Contact Us links on the MAG-FAST® website at: www.mag-fast.com